


INSTALLATION RECOMMENDATIONS

1. WE RECOMMEND ALL TRAY SYSTEMS TO BE INSTALLED BY A QUALIFIED CONTRACTOR FAMILIAR WITH TRACK AND FIELD CONSTRUCTION AND ALL LOCAL CODES AND RESTRICTIONS.
2. TRAY MUST BE SURROUNDED BY 4" OF CONCRETE, BOTTOM, SIDES, AND ENDS.
3. A WATER DRAIN MAY BE PLACED UNDER TRAY IF DESIRED, PROVIDING DRAIN RUNS TO AN APPROVED DRAINAGE SYSTEM.
4. LEVELING BOLTS CAN BE ADJUSTED TO BRING BOARD UP TO FLUSH WITH THE RUNWAY SURFACE MATERIAL.

www.stackhouseathletic.com



Phone: (503) 363-1840 Toll Free: (800) 285-3604
 Fax: (503) 363-0511 www.stackhouseathletic.com

SYNTHETIC TAKE-OFF BOARD WITH STEEL TRAY

INSTALLATION DRAWING

PAGE 1 of 1

PRODUCT CODE: TTSS

SCALE: NTS
DATE: 12-08
DRAWN BY: S.L.
DWG: TTSS INSTALL-REV-08